



OFF HIGHWAY VAN

SPRINTER OVERDRIVER SHELF 2019-2022 (VS30)



Thank you for purchasing the Off Highway Van Sprinter Overdriver Shelf. A convenient and sturdy overhead headliner shelf designed to hold window shades or curtains, as well as everyday items that you might need quicker access to while on the road, or at the trailhead. Take back space in your Sprinter and utilize a part of the van that's often overlooked. Easy to install, and a solid, trustworthy design you'd come to expect from OHV. This installation guide is meant to direct you through the easy and seamless installation process. Before beginning the assembly, visually inspect all components for defects in finish or craftsmanship and check that you have all the necessary hardware. Welcome to the OHV Crew.

PACKING LIST:

- (1) MAIN OVERDRIVER SHELF PANEL
- (2) FRONT SHELF BRACKETS
- (2) REAR SHELF BRACKETS
- (1) LINER/MAT
- HARDWARE:

DESCRIPTION

QTY

.250"x20x0.625" Button Head Screw 18-8 Stainless Steel Hex Drive	8
.250"x20 Nylon Insert Locknut 18-8 Stainless Steel	8
.250" Washer	16
No.8x0.500" Philips Flange Screw Extra-Wide Rounded Head Screw for Metal	2

RECOMMENDED TOOLS:

- POWERED DRILL
- ADDITIONAL PERSON FOR HOLDING SHELF UP
- PHILLIPS BIT FOR DRILL
- 7/16" OPEN-ENDED WRENCH
- 5/32" OR 4MM HEX TOOL
- T-25 TOOL



OFF
HIGHWAY
VAN

1210 S 3600 W
SALT LAKE CITY, UT 84104
OFFHIGHWAYVAN.COM
801.382.7374



INSTALLATION (TOTAL ESTIMATED TIME - 1 HOUR)

- 1. REMOVE REAR-MOST (AWAY FROM THE FRONT OF THE VAN) 4MM BOLTS FROM THE FACTORY MOUNTED SHELVES**
- 2. PLACE THE FRONT SHELF BRACKETS (PHOTO BELOW) BEHIND THE FACTORY SHELF MOUNTING POINT THAT WAS JUST REMOVED, AND REPLACE THE BOLT THAT WAS JUST REMOVED. TIGHTEN WITH THE LARGER PORTION OF THE BRACKET WITH THE TWO HOLES FACING UP.**



- 3. REMOVE THE RUBBER HOOK COVER, AND REMOVE THE T-25 BOLT HOLDING THE METAL HOOK.**





OFF HIGHWAY VAN

4. PLACE THE REAR SHELF BRACKETS (PHOTO BELOW) BEHIND THE TRIM, BOLT, AND HOOK THAT WAS JUST REMOVED. REPLACE THE T25 BOLT THROUGH THE TRIM, HOOK, AND MOUNT. TIGHTEN WITH THE LARGER PART OF THE BRACKET WITH TWO HOLES FACING UP AND REPLACE THE RUBBER HOOK COVER THAT WAS REMOVED.



5. REPEAT ON THE OPPOSITE SIDE
6. WITH THE HELP OF A FRIEND, PLACE THE MAIN SHELF ON TOP OF THESE BRACKETS AND LINE UP THE CORRESPONDING BOLT HOLES.
7. PLACE A WASHER UNDER THE BUTTONHEAD AND PUSH THE BUTTONHEAD SCREW UP THROUGH THE BOTTOM OF THE BRACKET AND THROUGH THE MAIN SHELF. PLACE THE OTHER WASHER ON TOP OF THE SHELF OVER THE SCREW AND BEGIN HAND-THREADING THE 7/16" NYLON-INSERT NUT ONTO THE SCREW AND WASHER. USE THE 5/32" OR 4MM ALLEN KEY AND AN OPEN ENDED 7/16 WRENCH TO TIGHTEN AND SNUG DOWN ALL 8 BOLTS – FRONT AND BACK, ON BOTH SIDES, WITH WASHERS UNDER EACH BUTTONHEAD, AND UNDER EACH NUT.



OFF
HIGHWAY
VAN

1210 S 3600 W
SALT LAKE CITY, UT 84104
OFFHIGHWAYVAN.COM
801.382.7374



OFF HIGHWAY VAN

8. USING A DRILL, DRIVE THE FINAL TWO PHILLIPS HEAD SCREWS INTO THE FRONT TWO MOUNTING HOLES TO FULLY SECURE THE SHELF.



9. LAY DOWN THE LINER/MAT
10. ENJOY A BEVERAGE FOR YOUR HARD WORK – AND GAIN BACK USABLE SPACE IN YOUR **SPRINTER VAN**.



**OFF
HIGHWAY
VAN**

1210 S 3600 W
SALT LAKE CITY, UT 84104
OFFHIGHWAYVAN.COM
801.382.7374